


# SAMSON

## INSTRUCTIONS


### Attaching the Lanyard to the AirLine AL1 Transmitter

1. Pass the cord from the Transmitter Tie Clasp through the holes on the top rear of the AL1. The AL1 tie clip may have to be rotated (and can be removed) to reveal the exit hole. See the AirLine Owners Manual for further instructions. For clarity, the figures below show the AL1 with the tie clip removed.
2. Pull the cord all the way through and lift it over the clasp making a loop. Pull the clasp through the loop taking up the slack.
3. Place the Lanyard over the head of the person using the transmitter, adjusting the length with the Lanyard Length Adjustment Clasp which should be at the back of the persons neck (refer to figure: step 4). Insert the Lanyard Clip into the Transmitter Tie Clasp until it snaps.
4. The AL1 Transmitter should rest approximately in the middle of the chest of the person speaking (figure 9). To increase signal to the mic, adjust the AL1 closer to the person's mouth using the Lanyard Length Adjustment Clasp.


To temporarily remove the Lanyard from the AL1, squeeze the clasp and release the clip.




Step 1



Step 2



Step 3



Step 4

If you experience any difficulties, or require further assistance, contact Samson Customer Service at 1-800-3SAMSON (1-800-372-6766) M-F 9AM to 5PM (eastern standard time). For more product information please visit our website at [www.samsontech.com](http://www.samsontech.com).

# SAMSON

575 Underhill Blvd, P.O. Box 9031, Syosset, N.Y. 11791-9031 • Tel. 1-516-364-2244 Fax. 1-516-364-3888